

**Installation instructions for the Wilhelm Raceworks APR Mirror Mounting Plates for the MKII MR2.  
APR GT3 Mirrors not included.**

**Note:** The plates are unique left to right. They may be identified by the corners. The rounded corner points up, the pointy corner points forward.

1. Installation does not *require* drilling of any holes. However, you may want to use the mounting plate as a template to mark and drill a hole in the location shown below to allow access to the tension screw on the bottom of the APR mirror pivot. This will make it easier to adjust the mirrors and then lock them in the correct position without needing to remove the plate.



2. Install the APR mirror to the plate using the supplied countersunk screw, washer, and nut in the lower hole as shown below. Use caution at this stage to avoid scratching the powder coating on the mounting plate:



3. Install the mirror / plate assembly to the car. One additional nut / washer on the previously installed lower bolt, and a nut and washer on the other countersunk screw in the upper mirror hole. This screw will come through the corner of the square opening in the stock mounting place, and the washer and screw will sandwich it all together.
4. Install the two remaining button head screws with washers and nuts. If you are re-installing the stock tweeter brackets they can be installed under these two nuts.

